

## Установка персонального кода

При открытой дверце нажмите красную кнопку сброса (слева на внутренней торцевой стороне дверцы) - загорится жёлтая лампочка, затем введите свой 3 - 8- и значный для подтверждения.

Последуют два звуковых сигнала, цифровой код и нажмите которые означают, что новый код был принят и сохранён.

## Открытие сейфа

Введите персональный код - последует один звуковой сигнал и жёлтая лампочка мигает.

Затем нажмите \*\*\* для подтверждения - загорится зелёная лампочка, поверните круглую ручку и потяните на себя - дверца открыта.

Если Вы ввели код неправильно, последуют 5 звуковых сигналов.

Если три раза подряд код введён не правильно, клавиатура будет заблокирована и звуковой сигнал будет подаваться в течении 20 секунд.

Если по истечении 20 секунд код снова будет введён не правильно 3 раза, клавиатура будет заблокирована, звуковой сигнал будет подаваться в течении 5 минут.

Закрытие сейфа Введите код, зелёная лампочка будет мигать в течении 5 секунд. Затем поверните круглую ручку, сейф закроется через 5 секунд. Внимание!!!

Если одновременно горят красная и зелёная лампочки, это означает, что нужно поменять батареи.

Пожалуйста сделайте проверку перед закрытием дверцы.

## The setting of a personal code

When the door is open, press the red reset button (left on the inner side of the door) - the yellow light will light up, then enter your 3 - 8 digit to confirm.

There will be two signals, a digital code and a click which means that the new code has been accepted and saved.

## Opening the safe

Enter your personal code - there will be one signal and the yellow light will flash.

Then press \*\*\* to confirm - the green light will light up, turn the round handle and pull - the door is open.

If You entered the code correctly, you will hear 5 beeps. If the code is entered incorrectly three times in a row, the keypad will be locked and the sound signal will be given within 20 seconds.

If after 20 seconds the code is not entered correctly 3 times, the keyboard will be locked, the sound will be given within 5 minutes.

Closing the safe Enter the code, the green light will flash for 5 seconds.

Then turn the round handle, the safe will close after 5 seconds.

Attention!!! If the red and green lights are on at the same time, it means that you need to change the batteries.

Please do a check before closing the door.